

# T09 10" SAND GUZZLER

BY

Tibban MFG. Inc.

[SandGuzzler.com](http://SandGuzzler.com)

*Please read Completely before operating.*

## Installation:

Connect the hydraulic hoses so as to make the impeller rotate in a clockwise rotation as viewed from the top of the pump.

- Dig a ditch from the well being drilled to a small pit just outside the drill. Set the Sand Guzzler in the pit deep enough for the mud to cover the hydraulic motor.
- The mud in the pit will rise and fall during normal operation. The speed should be adjusted so as to make the pump run about 100 RPM faster than needed to pump all the drilling fluid.
- The Sand Guzzler can run dry. There are no seals or bearings in the mud. The air will discharge from the SAND GUZZLER automatically while operating.
- ***Caution: Keeps hands away from the impeller. Serious injury or death can occur.***

## Hydraulic Hoses:

A case drain is a must for hydraulic motors on the Sand Guzzler pumps. The case will drain oil from the shaft seal to protect it from leaking. The motor can be reversed momentarily when needed to clear a rock or clog.

The case drain hose should be routed back to the hydraulic tank with no obstruction between. The Motor seal will withstand up to 100 PSI of return back pressure. If the return line pressure exceeds 100 psi, the shaft seal will be pushed out and will leak oil.

The SAND GUZZLER pump will run best at about 1200 RPM. The faster the pump turns the faster the housing will wear. The SAND GUZZLER can be run as fast as 3000 RPM and will take up to 3000 psi.

## Hydraulic Motor:

Eaton Piston motor 1.52 CID

Max. RPM 3000

Max. PSI: 5000 Continuous

19 Gallons per minute at 3000 RPM

8 Gallons per minute at 1200 RPM

PO Box 2675

Apple Valley, CA 92307-2675

760/961-1160 Office

760/961-1126 Fax

[Info@Tibban.com](mailto:Info@Tibban.com)